

HomeAware® II

HA360MBK - Basic Starter Kit

Setting Up Your HomeAware™ Main Unit for the First Time

Remove all contents of the box.

- HA360M-II - Main Unit
- HA360V-II - Bed Shaker
- Quick Start Guide

Connecting the Power Supply and Bed Shaker to the Main Unit

Plug the power supply cord from the HA360M-II main unit into the 5.1V 2A DC IN connector on the back of the main unit and then plug the power supply into a 120V outlet.

Plug the cord of the shaker into the bed shaker jack on the back of the main unit. The bed shaker can be placed under either the pillow or mattress. If it is under the pillow, the vibration will be stronger, but it could fall off the bed during the night and you might not feel the vibration in the case of an emergency. If the bed shaker is placed under the mattress, the vibration may be weaker but there is less risk of it falling away.

MISSING SHAKER will scroll across the display until the optional (HA360V-II) shaker is plugged into Bed shaker 5V port. Press **ALARM OFF** button to clear the scrolling message. If you are not using the shaker press the **SET UP** button and the word **LINK** will be shown on the display. Press the **TONE** button until the word **s SENS** is shown on the display, press **ENTER**. Press the **TONE** button to toggle between **ON** and **OFF**, press **ENTER** on your selection.



Install Rechargeable Battery

Remove the battery cover from the bottom of the HA360M-II main unit. Fully insert the battery connector into the matching socket inside of the battery compartment. Push until you feel or hear a click to let you know it is in all the way. Insert the battery into the battery compartment, taking care not to unplug or put stress on the battery cable. Reinstall the battery cover and make sure it clicks into place.



Setting the Time of Day

Press the **TIME SET** button. Blinking red dots shown on the display indicate time set mode has been activated. Press the **HOURLY** buttons up or down and the **MINUTES** buttons up or down to set the desired time. The PM indicator is located on the top left-hand side. Press the **ENTER** button when done to complete the time setting. The display dots will stop blinking to indicate the time has been set.

For additional information refer to the HA360M-II and HA360V-II user guides.

INSTALLING THE HOMEWARE® APP

The HomeAware® II App must be installed on your smart phone to alert you to an incoming telephone call or text message and to receive firmware updates. This app is necessary when subscribed to the HomeAware® II Subscription Service. This app is not necessary for the smoke and CO alert function of the HA360M-II to work.

1. Install the HomeAware app on your smartphone. Available for iOS on the Apple App Store®, and for Android™ on the Google Play™ Store.
2. Follow the instructions in the HomeAware app to link your smartphone with the HA360M-II.

Note: Reference the HomeAware App Step-By-Step Guide located at www.sonicalert.com/HomeAware-II-Basic-Starter-Kit (User Guide tab).